

Ventilation System 2

- Floors 1 and 2 have ventilation louvres on the outside walls. There is a separate control for the top half (high level) and another for the low level.
- Please note that when you adjust the level of the ventilation it takes approx. 2mins to take effect.
- It is the inner vertical doors that move not the louvres and a green light shows the action is complete.
- In the winter, please ensure the dial is set to the 0% position when you leave in the evening and conversely leave in the fully open position overnight in the summer to purge the building on hot days.

